3G/HD/SD-SDI Video Routers in the VikinX Sublime series

User manual

Rev. 21

Nevion Support

Nevion Europe

P.O. Box 1020
3204 Sandefjord, Norway

Support phone 1: +47 33 48 99 97
Support phone 2: +47 90 60 99 99

Nevion USA

1600 Emerson Avenue
Oxnard, CA 93033, USA

Toll free North America: (866) 515-0811
Outside North America: +1 (805) 247-8560

E-mail: support@nevion.com
See http://www.nevion.com/support/ for service hours for customer support globally.

Revision history

Current revision of this document is the uppermost in the table below.

Rev.	Repl.	Date	Sign	Change description
21	20	2011-12-20	AAA	Added comment for the MRP protocol option in Chapter 3.7. Fan error alarm described in chapter 4.2 and Appendix B.1 and B.2.
20	19	2011-10-26	NBS	Added Chapter 2.6.1.
19	18	2011-08-22	NBS	Updated Chapter 7.1.2.
18	17	2011-07-14	NBS	Added Appendix B. Added Grass Valley Native Protocol in Chapter 3.7 and Appendix B.2. Added Chapter 7.1.10. Changed Chapter 7.1.1. Undone moving Chapter 3 to Chapter 2. Updated Declaration of Conformity.
17	16	2011-03-23	NBS	Added 16x2 protocol info in Chapter 2.13; Updated wiring information in Chapter 5.2; Corrected housing and gender spec on D-sub 9-pin contacts. Removed old Revision history; Moved chapter 3 to chapter 2.
16	15	2011-01-25	NBS	Added chapters 2.1.1, 3.8 and 0. Updated chapters 3.7, 4.2 and 7.1.8. Added Non-Square / partly configured routers. Updated Declaration of Conformity.

Contents

1 Product overview 5
1.1 Product versions 5
2 Specifications 9
2.1 Mechanics 9
2.1.1 Weight and power consumption 9
2.2 Power Supply 9
2.3 Control 10
2.4 SD-SDI specifications 10
2.5 3G/HD-SDI specifications 11
2.6 Connection details 12
2.6.1 Power Supply pin-out 13
3 Configuration 14
3.1 Router level 14
3.2 Router mode 14
3.2.1 Router mode on NxN square routers 14
3.2.2 Router extension mode on 16x2 routers 19
3.3 Power alarm 19
3.4 Power-up mode / Extension enable 19
3.5 Configuring output on Single bus panels 20
3.6 Configuring switching time 20
3.7 Configuring protocol options 20
3.8 Configuring Input options 22
3.8.1 Input EQ 22
3.9 Configuring Output options 23
3.9.1 Output reclocker 23
3.9.2 Slew rate settings 23
3.9.3 Laser settings 23
4 LED status indication 25
4.1 Start-up 25
4.2 Alarm states 25
4.3 Ethernet states 25
5 Router communication 26
5.1 Serial connection 26
5.1.1 Maximum cable length (RS-232) 26
5.2 Ethernet connection 27
5.2.1 HW limitations 27
5.3 NCB connection 28
5.3.1 Connecting control panels 28
5.3.2 Pin-out and cable type 28
5.3.3 Termination plug 28
5.3.4 Control bus structure 29
5.3.5 Maximum distance between NCB devices 29
6 Connecting signal cables to the router 30
6.1 Video signals 30
6.2 Input extension 30
7 Control Panel operation 32
7.1 Button description 32
7.1.1 A/V Toggle 32

7.1.2 Panel Enable 33
7.1.3 Take on/off 33
7.1.4 Take 33
7.1.5 Output 33
7.1.6 Input 33
7.1.7 XY 33
7.1.8 Salvo 33
7.1.9 Lock 34
7.1.10 Protect 34
General environmental requirements for Nevion equipment 35
Product Warranty 36
Important notes regarding Software in the VikinX Sublime router family range 37
Appendix A Materials declaration and recycling information 38
A.1 Materials declaration 38
A.2 Recycling information 38
Appendix B Additional Protocol information 39
B.1 Leitch Pass-Through protocol 39
B.2 Grass Valley Native protocol 39
EC Declaration of Conformity 41

1 Product overview

Nevion are proud to present the 2nd generation of the compact small and medium routing switcher family, Sublime. With Sublime, Nevion now provide a stable and proven product line including the most complete signal format and size offering available.

With the new ultra slim, multi format and flexible product range, Sublime fulfils the most demanding requirements from the professional broadcast market.

This User Manual presents the features, installation and operation procedures of the SD and 3G HD / HD routers of the Sublime range.

- Router range from 8x8 to 128x128
- Software based Configurator for easy system set-up
- TCP/IP, RS-232 and NCB Control (RJ-45)
- Programmable multi- single- and dual bus control panels
- Ultra Slim frame depth
- Low Power, high reliability design
- Redundant power supply system with front indicators
- Interoperability with existing VikinX routers
- Future proof and flexible product range

VikinX Sublime provides many of the powerful control features that drove the VikinX Modular range to success. VikinX Sublime is ideal for general purpose facilities, on-air routing, mobile outside broadcast applications and sophisticated A/V applications.

1.1 Product versions

The following versions of the VikinX Sublime 3G/HD/SD-SDI Routers are available:

SD Digital Video – 19” - 1RU, depth 5cm:

SL-SD0808-R / SL-SD0808-R-CP	8x8 SD Digital Video Router (540Mbps). Router partitioning. Reclocking. Programmable X-Y control panel (on CP version)
SL-SD0808-N / SL-SD0808-N-CP	8x8 SD Digital Video Router (540Mbps). Router partitioning. Non-reclocking. Programmable X-Y control panel (on CP version)
SL-SD1616-R / SL-SD1616-R-CP	16x16 SD Digital Video Router (540Mbps). Router partitioning. Reclocking. Programmable X-Y control panel (on CP version).
SL-SD1616-N / SL-SD1616-N-CP	16x16 SD Digital Video Router (540Mbps). Router partitioning. Non-reclocking. Programmable X-Y control panel (on CP version).
SL-SD1602-R / SL-SD1602-R-CP	16x2 SD Digital Video Router (540Mbps). Reclocking. Programmable Dual bus control panel (on CP version), Expandable to 64x2.

SD Digital Video – 19” - 2RU, depth 5cm:

SL-SD3232-R / SL-SD3232-R-CP	32x32 SD Digital Video Router (540Mbps). Router partitioning. Reclocking. Programmable X-Y control panel (on CP version).
SL-SD3232-N / SL-SD3232-N-CP	32x32 SD Digital Video Router (540Mbps). Router partitioning. Non-reclocking. Programmable X-Y control panel (on CP version).

SD Digital Video – 19” - 4RU, depth 5cm:

SL-SD6464-R / SL-SD6464-R-CP	64x64 SD Digital Video Router (540Mbps). Router partitioning. Reclocking. Programmable X-Y control panel (on CP version).
SL-SD6464-N / SL-SD6464-N-CP	64x64 SD Digital Video Router (540Mbps). Router partitioning. Non-reclocking. Programmable X-Y control panel (on CP version).

3G-HD / HD Digital Video – 19" - 1RU, depth 5cm:

SL-3GHD0808 / SL-3GHD0808-CP	8x8 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Router partitioning. Reclocking. Programmable X-Y control panel (on CP version).
SL-3GHD1616 / SL-3GHD1616-CP	16x16 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Router partitioning. Reclocking. Programmable X-Y control panel (on CP version).
SL-3GHD1602 / SL-3GHD1602-CP	16x2 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable Dual bus control panel (on CP version).
SL-HD0808-N / SL-HD0808-N-CP	8x8 HD Digital Video Router (1.5Gbps). Router partitioning. Non-reclocking. Programmable X-Y control panel (on CP version).
SL-HD1616-N / SL-HD1616-N-CP	16x16 HD Digital Video Router (1.5Gbps). Router partitioning. Non-reclocking. Programmable X-Y control panel (on CP version).

3G-HD / HD Digital Video – 19" - 2RU, depth 5cm:

SL-3GHD3232 / SL-3GHD3232-CP	32x32 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Router partitioning. Reclocking. Programmable X-Y control panel (on CP version).
SL-HD3232-N / SL-HD3232-N-CP	32x32 HD Digital Video Router (1.5Gbps). Router partitioning. Non-reclocking. Programmable X-Y control panel (on CP version).

3G-HD / HD Digital Video – 19" - 4RU, depth 5cm:

SL-3GHD6464 / SL-3GHD6464-CP	64x64 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Router partitioning. Reclocking. Programmable X-Y control panel (on CP version).
SL-HD6464-N / SL-HD6464-N-CP	64x64 HD Digital Video Router (1.5Gbps). Router partitioning. Non-reclocking. Programmable X-Y control panel (on CP version).

Non-square / partly configured 3G-HD routers – 19" - 1RU, depth 5cm:

Based on SL-3GHD1616 / SL-3GHD1616-CP:

SL-3GHD0808+ / SL-3GHD0808+-CP	8x8 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable X-Y control panel (on CP version).
SL-3GHD1608 / SL-3GHD1608-CP	16x8 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable X-Y control panel (on CP version).
SL-3GHD0816 / SL-3GHD0816-CP	8x16 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable X-Y control panel (on CP version).

Based on SL-3GHD1602 / SL-3GHD1602-CP:

SL-3GHD1601 / SL-3GHD1601-CP	16x1 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable Single bus control panel (on CP version).

Non-square / partly configured 3G-HD routers – 19" - 2RU, depth 5cm:

Based on SL-3GHD3232 / SL-3GHD3232-CP:

SL-3GHD1616+ / SL-3GHD1616+-CP	16x16 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Router partitioning. Reclocking. Programmable X-Y control panel (on CP version).
SL-3GHD3216 / SL-3GHD3216-CP	32x16 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable X-Y control panel (on CP version).
SL-3GHD1632 / SL-3GHD1632-CP	16x32 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable X-Y control panel (on CP version).

SL-3GHD3208 / SL-3GHD3208-CP	32x8 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable X-Y control panel (on CP version).
SL-3GHD0832 / SL-3GHD0832-CP	8x32 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable X-Y control panel (on CP version).

Non-square / partly configured 3G-HD routers – 19" - 4RU, depth 5cm:

Based on SL-3GHD6464 / SL-3GHD6464-CP:

SL-3GHD3232+ / SL-3GHD3232+-CP	32x32 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Router partitioning. Reclocking. Programmable X-Y control panel (on CP version).
SL-3GHD6432 / SL-3GHD6432-CP	64x32 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable X-Y control panel (on CP version).
SL-3GHD3264 / SL-3GHD3264-CP	32x64 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable X-Y control panel (on CP version).
SL-3GHD6416 / SL-3GHD6416-CP	64x16 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable X-Y control panel (on CP version).
SL-3GHD1664 / SL-3GHD1664-CP	16x64 HD Digital Video Router (Multirate, 270Mbps-2.97Gbps). Reclocking. Programmable X-Y control panel (on CP version).

Upgrades of non-square /partly configured routers:

I/O on partly configured routers starts from I/O #1 and up.

Upgrades expands the number of available I/O above those I/O's that were already available before the upgrade.

SL-UPG-1OUT	Upgrade from SL-3GHD1601 to SL-3GHD1602.
SL-UPG-8IN	Upgrade to add 8x Inputs to your partly configured SL-3GHD1616 or SL-3GHD3232 router.
SL-UPG-8OUT	Upgrade to add 8x Outputs to your partly configured SL-3GHD1616 or SL-3GHD3232 router.
SL-UPG-8IN+OUT	Upgrade to add 8x Inputs and Outputs to your partly configured SL-3GHD1616 or SL-3GHD3232 router.
SL-UPG-16IN	Upgrade to add 16x Inputs to your partly configured SL-3GHD3232 or SL-3GHD6464 router.
SL-UPG-16OUT	Upgrade to add 16x Outputs to your partly configured SL-3GHD3232 or SL-3GHD6464 router.
SL-UPG-16IN+OUT	Upgrade to add 16x Inputs and Outputs to your partly configured SL-3GHD3232 or SL-3GHD6464 router.

Available Control Panels – 19" – 1RU:

SL-16XY-CP	Multi bus X-Y 16x16 panel.
SL-8XY-CP	Multi bus X-Y 8x8 panel.
SL-16D-CP	Dual bus 16x2 panel.
SL-32S-CP	Single bus 32x1 panel.
SL-32S-CP-GPI	Single bus 32x1 panel with GPI / Joystick / Tally interface.
SL-16S-CP	Single bus 16x1 panel.
SL-16S-CP-GPI	Single bus 16x1 panel with GPI / Joystick / Tally interface.
SL-8S-CP	Single bus 8x1 panel.
SL-8S-CP-GPI	Single bus 8x1 panel with GPI / Joystick / Tally interface.
SL-16XY-CP	Multi bus X-Y 16x16 panel.

Available Control Panels – 19" – 2RU:

SL-32XY-CP	Multi bus X-Y 32x32 panel.
SL-64S-CP	Single bus 64x1 panel.
SL-64S-CP-GPI	Single bus 64x1 panel with GPI / Joystick / Tally interface.

Available Control Panels – 19" – 4RU:

SL-64XY-CP	Multi bus X-Y 64x64 panel.

2 Specifications

2.1 Mechanics

Dimensions:
- HxWxD = 44x483x50mm, (19”, 1RU);
- HxWxD = 88x483x50mm, (19”, 2RU);
- HxWxD = 176x483x50mm, (19”, 4RU).

Safety/Emission standards: Compliant with CE EN55103-1 and 2.

2.1.1 Weight and power consumption

Device	Weight, incl. 1x PSU	Current +15V	Current -15V	Power
SL-3GHD6464	3.4 kg	2530 mA	1908 mA	67 W
SL-3GHD6464-CP	4.0 kg	2844 mA	1947 mA	72 W
SL-3GHD3232	1.9 kg	1174 mA	1016 mA	33 W
SL-3GHD3232-CP	2.2 kg	1302 mA	1035 mA	35 W
SL-3GHD1616	1.3 kg	1200 mA	2 mA	18 W
SL-3GHD1616-CP	1.4 kg	1273 mA	4 mA	19 W
SL-3GHD0808	1.2 kg	700 mA	2 mA	11 W
SL-3GHD0808-CP	1.3 kg	900 mA	2 mA	14 W
SL-3GHD1602	1.2 kg	487 mA	3 mA	7 W
SL-3GHD1602-CP	1.3 kg	700 mA	2 mA	11 W
SL-HD6464-N	3.4 kg	1500 mA	950 mA	37 W
SL-HD6464-N-CP	4.0 kg	2500 mA	950 mA	52 W
SL-HD3232-N	1.9 kg	1300 mA	2 mA	20 W
SL-HD3232-N-CP	2.1 kg	1360 mA	3 mA	20 W
SL-HD1616-N	1.2 kg	700 mA	3 mA	11 W
SL-HD1616-N-CP	1.4 kg	880 mA	4 mA	13 W
SL-HD0808-N	1.2 kg	500 mA	2 mA	8 W
SL-HD0808-N-CP	1.3 kg	600 mA	2 mA	9 W
SL-SD6464-R	3.3 kg	2550 mA	1950 mA	68 W
SL-SD6464-R-CP	4.0 kg	3500 mA	1950 mA	82 W
SL-SD3232-R	1.9 kg	1200 mA	1030 mA	33 W
SL-SD3232-R-CP	2.2 kg	1750 mA	1050 mA	42 W
SL-SD1616-R	1.2 kg	1204 mA	3 mA	18 W
SL-SD1616-R-CP	1.4 kg	1303 mA	3 mA	20 W
SL-SD0808-R	1.2 kg	704 mA	2 mA	11 W
SL-SD0808-R-CP	1.3 kg	900 mA	2 mA	14 W
SL-SD1602-R	1.2 kg	333 mA	54 mA	6 W
SL-SD1602-R-CP	1.3 kg	600 mA	120 mA	11 W
SL-SD6464-N	3.3 kg	1500 mA	950 mA	37 W
SL-SD6464-N-CP	4.0 kg	2470 mA	950 mA	51 W
SL-SD3232-N	1.8 kg	1200 mA	3 mA	18 W
SL-SD3232-N-CP	2.1 kg	1350 mA	3 mA	20 W
SL-SD1616-N	1.2 kg	689 mA	3 mA	10 W
SL-SD1616-N-CP	1.4 kg	800 mA	3 mA	12 W
SL-SD0808-N	1.2 kg	500 mA	2 mA	8 W
SL-SD0808-N-CP	1.3 kg	600 mA	2 mA	9 W

2.2 Power Supply

SL-PWR-40 40W Power Supply Unit for 8x8 – 32x32 versions.
SL-PWR-90 90W Power Supply Unit for 64x64 versions.
AC Supply voltage range: 100-240VAC, 50-60Hz,
Max 1.6A (SL-PWR-40) / Max 3A (SL-PWR-90).

AC Mains connector:	IEC 320.
DC output:	- +15V, max. 2.2A / -15V, max 1.35A. Maximum 43W for 8x8 – 32x32 versions; - +15V, max. 4A / -15V, max 2.5A. Maximum 90W for 64x64 versions.
DC connector:	DE9, D-sub 9-pin male.
Status monitoring:	Via LED in front of the router/CP.
Safety standards:	Compliant with CE EN60950, UL-1950/CSA22.2.

2.3 Control

Standard Features:

Serial port:	RS-232 for protocol conversion, to VikinX compact control protocol, or to third party protocols.
Connector:	DE9, D-sub 9-pin female.
NCB ports:	For integration with VikinX compact router configuration.
Connectors (2):	RJ45 (1 In / 1 Out)
Ethernet port:	10/100BaseT Ethernet bus for external router control.
Connector:	RJ45.
Synchronization:	- Analog Black&Burst, looped. Both PAL and NTSC supported. - Tri-Level, Looped. For HD signal formats only. - Distribution of synchronization signals between several routers.
Connector(s):	BNC.

Optional Features:

Control Panel:	- Optional, built-in control panel available. - External control panels available.

2.4 SD-SDI specifications

Supported formats:

Broadcast:	143Mbps – 540Mbps.

Supported standards:

SD-SDI, 270Mbps:	SMPTE 259M.
DVB-ASI:	EN50083-9.

Electrical signal inputs:

Connector:	BNC, IEC 61169-8.
Impedance:	75 Ohm.
Return loss:	> 15dB (5 MHz – 540 MHz).
Cable equalization, ***Reclocking*** routers:	Automatic up to 300m (@ 270Mbps, typical Belden 8281.
Cable equalization, ***Non-reclocking*** routers:	Automatic up to 200m (@ 270Mbps, typical Belden 8281.

Electrical signal outputs:

Connector:	BNC, IEC 61169-8.
Impedance:	75 Ohm.
Return loss:	> 15dB (5 MHz – 540 MHz).
Signal level:	800mVp-p ±10%.
Rise/fall time:	20% - 80% SD limit: 0.4ns – 1.5ns, < 0.5ns rise/fall variation.
Amplitude overshoot:	< 10%.
Signal polarity:	Non-inverting electrical with respect to inputs.

Signal transition:

Timing jitter:	SD: < 0.2 UI.

Alignment jitter: SD: < 0.2 UI.

Reference inputs:

Number of inputs: 1.

Connector: 75 ohm BNC female, loop-thru.

Return loss: >40dB (100 kHz – 5 MHz);
>35dB (5-10 MHz).

Signal format: NTSC or PAL Black&Burst.

Signal level: Nominal 1.0Vp-p.

Field selectivity: Field 1.

Timing range:
- PAL: within clock-intervals (27MHz) 565 – 835 in line 6
- NTSC: within clock-intervals (27MHz) 565 – 835 in line 10.

2.5 3G/HD-SDI specifications

Supported formats:

Broadcast:
- 270Mbps – 2.97Gbps;
- 2K, 2048x1556/23.98 and 24.

Supported standards:

SD-SDI, 270Mbps: SMPTE 259M.

HD-SDI, 1.485Gbps: SMPTE 292-2008.

3G-SDI, 2.97Gbps: SMPTE 424M.

DVB-ASI: EN50083-9.

Electrical signal inputs:

Connector: BNC, IEC 61169-8.

Impedance: 75 Ohm.

Return loss:
- > 15dB (5MHz-1.485Ghz);
- > 10dB (1.5GHz – 3GHz).

Cable equalization,
Reclocking routers:
- Automatic up to 70m (@ 2.97Gbps, typical Belden 1694A;
- Automatic up to 100m @ 1.485Gbps, typical Belden 1694A.

Cable equalization,
Non-reclocking routers: Automatic up to 25m (@1.485Gbps, typical Belden 1694A.

Electrical signal outputs:

Connector: BNC, IEC 61169-8.

Impedance: 75 Ohm.

Return loss:
- > 15dB (5MHz-1.485Ghz);
- > 10dB (1.5GHz – 3GHz).

Signal level: 800mVp-p ±10%.

Rise/fall time: 20% - 80%
- SD limit: 0.4ns – 1.5ns, < 0.5ns rise/fall variation;
- HD limit: < 270ps, < 100ps rise/fall variation;
- 3G-HD limit: < 135ps, < 50ps rise/fall variation;

Amplitude overshoot: < 10%.

Signal polarity: Non-inverting electrical with respect to inputs.

Signal transition:

Timing jitter:
- SD: < 0.2 UI
- 3G-HD / HD: < 1 UI.

Alignment jitter:
- SD: < 0.2 UI
- 3G-HD / HD: < 0.2 UI.

Reference inputs:

Number of inputs: 1.

Connector:	75 ohm BNC female, loop-thru.
Return loss:	>40dB (100 kHz – 5 MHz); >35dB (5-10 MHz).
Signal format:	NTSC or PAL Black&Burst or HD Tri-Level according to SMPTE 274M, SMPTE 276M.
Signal level:	Nominal 1.0Vp-p.
Field selectivity:	Field 1.
Timing range:	- SD, PAL: within clock-intervals (27MHz) 565 – 835 line 6 - SD, NTSC: within clock-intervals (27MHz) 565 – 835 line 10. - HD Tri-Level: 1280x720: within clock-intervals (148.5MHz) 455 – 780 line 7 - HD Tri-Level: 1920x1080: within clock-intervals (148.5MHz) 625 – 1070 line 7.

2.6 Connection details

The Sublime routers have the following service connections on the rear of each product:



Figure 1: Sublime service connectors.

SYNC:	Synchronization signal (in). Black burst/composite/tri-level sync reference input with passive loop-through for vertical interval switching.
LOOP:	Synchronization signal (out). Loop-through of SYNC input.
NCB IN:	Network Control Bus Input. The protocol of this bus is described in a separate manual.
NCB OUT:	Network Control Bus Output.
ETHERNET:	10/100Base-T Ethernet bus for external router control.
RS 232:	RS-232 for external control protocols.
POWER A:	±15VDC power socket.
POWER B:	±15VDC power socket, redundant supply.
CONFIGURATION:	Configurations switch. See Chapter 3 for further descriptions.

2.6.1 Power Supply pin-out

The DE9 male sockets for the power connection on Sublime routers and Control Panels have the following pin-out;

Pin #	Description
1	GND
2	Not connected
3	Not connected
4	+15VDC
5	Not connected
6	Not connected
7	Not connected
8	-15VDC
9	Not connected

3 Configuration

3.1 Router level

Switches 1 - 4 on the configuration switch set the router's level for communication with the Router Management System and other units in the NCB system. The panels on the NCB dedicated to operate with the router must be configured to the same level as that router.

If several routers are combined to form an Audio Follow Video, RGB or similar system, these routers must be configured to the same level.

The levels can be switched according to the following pattern:

SW 1	SW 2	SW 3	SW 4	Level	NCB Address
OFF	OFF	OFF	OFF	1	0
OFF	OFF	OFF	**ON**	2	1
OFF	OFF	**ON**	OFF	3	2
OFF	OFF	**ON**	**ON**	4	3
OFF	**ON**	OFF	OFF	5	4
OFF	**ON**	OFF	**ON**	6	5
OFF	**ON**	**ON**	OFF	7	6
OFF	**ON**	**ON**	**ON**	8	7
ON	OFF	OFF	OFF	9	8
ON	OFF	OFF	**ON**	10	9
ON	OFF	**ON**	OFF	11	10
ON	OFF	**ON**	**ON**	12	11
ON	**ON**	OFF	OFF	13	12
ON	**ON**	OFF	**ON**	14	13
ON	**ON**	**ON**	OFF	15	14
ON	**ON**	**ON**	**ON**	16	15

Default level is 1.

3.2 Router mode

This chapter does not apply to non-square / partly configured routers.

3.2.1 Router mode on NxN square routers

The nxn square Sublime A/V router allows switching in different modes:

Router layers	8x8 router	16x16 router	32x32 router	64x64 router
1 layer	8x8	16x16	32x32	64x64
2 layers	4x4	8x8	16x16	32x32
3 layers	N.A.	5x5	10x10	21x21
4 layers	2x2	4x4	8x8	16x16

Switches 5 - 6 on the configuration switch set the router's mode. The Router Management System software must be configured according to the mode chosen on the router.

The modes can be switched according to the following pattern:

SW 5	SW 6	Router mode
OFF	OFF	1 router layer
OFF	**ON**	2 router layers
ON	OFF	3 router layers
ON	**ON**	4 router layers

Default mode is 1 router layer.

Based on the configuration above, the I/O is connected to the router according to the following scheme, where the physical limitations depend on the type of router that is purchased (8x8, 16x16, 32x32 or 64x64):

- **1 layer:**
  I/O is connected according to information on the rear of the router.
- **2 layers, based on an 8x8 router:**

Layer 1	Input	Layer 1	Output
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
Layer 2	**Input**	**Layer 2**	**Output**
1	5	1	5
2	6	2	6
3	7	3	7
4	8	4	8

- **2 layers, based on a 16x16 router:**

Layer 1	Input	Layer 1	Output
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
…	…	…	…
8	8	8	8
Layer 2	**Input**	**Layer 2**	**Output**
1	9	1	9
2	10	2	10
3	11	3	11
4	12	4	12
…	…	…	…
8	16	8	16

- **2 layers, based on a 32x32 router:**

Layer 1	Input	Layer 1	Output
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
…	…	…	…
16	16	16	16
Layer 2	**Input**	**Layer 2**	**Output**
1	17	1	17
2	18	2	18
3	19	3	19
4	20	4	20
…	…	…	…
16	32	16	32

- **2 layers, based on a 64x64 router:**

Layer 1	Input	Layer 1	Output
1	1	1	1
2	2	2	2
3	3	3	3

4	4	4	4
…	…	…	…
32	32	32	32
Layer 2	**Input**	**Layer 2**	**Output**
1	33	1	33
2	34	2	34
3	35	3	35
4	36	4	36
…	…	…	…
32	64	32	64

- **3 layers, based on a 16x16 router:**

Layer 1	**Input**	**Layer 1**	**Output**
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
Layer 2	**Input**	**Layer 2**	**Output**
1	6	1	6
2	7	2	7
3	8	3	8
4	9	4	9
5	10	5	10
Layer 3	**Input**	**Layer 3**	**Output**
1	11	1	11
2	12	2	12
3	13	3	13
4	14	4	14
5	15	5	15

In-/Output 16 is not in use in this router setup (3 router layers, based on a 16x16 router).

- **3 layers, based on a 32x32 router:**

Layer 1	**Input**	**Layer 1**	**Output**
1	1	1	1
2	2	2	2
3	3	3	3
…	…	…	…
10	10	10	10
Layer 2	**Input**	**Layer 2**	**Output**
1	11	1	11
2	12	2	12
3	13	3	13
…	…	…	…
10	20	10	20
Layer 3	**Input**	**Layer 3**	**Output**
1	21	1	21
2	22	2	22
3	23	3	23
…	…	…	…
10	30	10	30

In-/Outputs 31 and 32 are not in use in this router setup (3 router layers, based on a 32x32 router).

– **3 layers, based on a 64x64 router:**

Layer 1	Input	Layer 1	Output
1	1	1	1
2	2	2	2
3	3	3	3
…	…	…	…
21	21	21	21
Layer 2	**Input**	**Layer 2**	**Output**
1	22	1	22
2	23	2	23
3	24	3	24
…	…	…	…
21	42	21	42
Layer 3	**Input**	**Layer 3**	**Output**
1	43	1	43
2	44	2	44
3	45	3	45
…	…	…	…
21	63	21	63

In-/Output 64 is not in use in this router setup (3 router layers, based on a 64x64 router).

– **4 layers, based on an 8x8 router:**

Layer 1	Input	Layer 1	Output
1	1	1	1
2	2	2	2
Layer 2	**Input**	**Layer 2**	**Output**
1	3	1	3
2	4	2	4
Layer 3	**Input**	**Layer 3**	**Output**
1	5	1	5
2	6	2	6
Layer 4	**Input**	**Layer 4**	**Output**
1	7	1	7
2	8	2	8

– **4 layers, based on a 16x16 router:**

Layer 1	Input	Layer 1	Output
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
Layer 2	**Input**	**Layer 2**	**Output**
1	5	1	5
2	6	2	6
3	7	3	7
4	8	4	8
Layer 3	**Input**	**Layer 3**	**Output**
1	9	1	9
2	10	2	10

3	11	3	11
4	12	4	12
Layer 4	**Input**	**Layer 4**	**Output**
1	13	1	13
2	14	2	14
3	15	3	15
4	16	4	16

– **4 layers, based on a 32x32 router:**

Layer 1	**Input**	**Layer 1**	**Output**
1	1	1	1
2	2	2	2
…	…	…	…
8	8	8	8
Layer 2	**Input**	**Layer 2**	**Output**
1	9	1	9
2	10	2	10
…	…	…	…
8	16	8	16
Layer 3	**Input**	**Layer 3**	**Output**
1	17	1	17
2	18	2	18
…	…	…	…
8	24	8	24
Layer 4	**Input**	**Layer 4**	**Output**
1	25	1	25
2	26	2	26
…	…	…	…
8	32	8	32

– **4 layers, based on a 64x64 router:**

Layer 1	**Input**	**Layer 1**	**Output**
1	1	1	1
2	2	2	2
…	…	…	…
16	16	16	16
Layer 2	**Input**	**Layer 2**	**Output**
1	17	1	17
2	18	2	18
…	…	…	…
16	32	16	32
Layer 3	**Input**	**Layer 3**	**Output**
1	33	1	33
2	34	2	34
…	…	…	…
16	48	16	48
Layer 4	**Input**	**Layer 4**	**Output**
1	49	1	49
2	50	2	50
…	…	…	…
16	64	16	64

3.2.2 Router extension mode on 16x2 routers

This chapter does not apply to partly configured (16x1) routers.

Switches 5 - 6 and 8 on the configuration switch set the router's input offset in systems with 2 or more 16x2 Sublime routers. You may build routers up to 64x2 with video formats. The chosen input offset defines the input range each 16x2 router works on.

Note that Router extension is NOT available on 3G/HD-SDI routers.

Configurable panels cannot detect input offset on 16x2 routers. It is therefore important to remember to re-program the local control panel on 16x2 routers with input offset >0. See also Chapter 7 for more information.

The modes of the video routers can be switched according to the following pattern:

SW 5	SW 6	SW 8	Input offset
OFF	OFF	**ON**	0 (Inputs 1-16)
OFF	**ON**	**ON**	1 (Inputs 17-32)
ON	OFF	**ON**	2 (Inputs 33-48)
ON	**ON**	**ON**	3 (Inputs 49-64)

Default mode is 0 offset.

See Chapter 3.4 for further information.

3.3 Power alarm

The power alarm can be switched according to the following pattern:

SW 7	Power alarm
OFF	Disables Power Alarm
ON	Enables Power Alarm

Default setting is Power Alarm disabled.

3.4 Power-up mode / Extension enable

Switch 8 on the configuration switch defines the power up mode on NxN square routers, and enables input extension on 16x2 routers. The Sublime router provides two modes for powering up the system.

The power up options can be switched according to the following pattern:

SW 8	Power Up mode
OFF	Switches all outputs according to the buffered information in the routers processor system.
ON	Switches all outputs to input 1.

Default setting switches all outputs according to the buffered information in the routers processor system.

On 16x2 routers this switch enables router extension. See further Chapter 0 for details.

SW 8	Extension enable
OFF	Disables input extension. Router works as 16x2 router.
ON	Enables input extension. Router works as 32x2, 48x2 or 64x2 router.

Default setting is extension disabled; the router works as a 16x2 router.

This feature does not apply to partly configured (16x1) routers.

3.5 Configuring output on Single bus panels

See Chapter 7.1, section Input for configuring default output to be controlled from a Single bus control panel.

3.6 Configuring switching time

> This configuration is done in the Nevion Configurator.

It is possible to configure switching time in the router. The settings are made through the Nevion Configurator, but a description of the options is given here. The user can select between three options;

1. Switch according to detected sync reference signal (Default).
   Switching time is determined by the synchronization signal that feeds the router. This is useful when the video signal has the same format as the synchronization signal. Supported formats are: PAL, NTSC, 750/50p, 750/60p, 1125/50i and 1125/60i.
2. Switch according to signal format: Select format.
   Here it is possible to use one synchronization signal to switch a different video format. A prerequisite is that the synchronization signal and the video signal have the same frame rate. E.g. Use PAL as synchronization signal with a 750/50p video signal. Supported formats are: PAL, NTSC, 750/50p, 750/60p, 1125/50i, 1125/60i, 1125/50p and 1125/60p.

   > We do not support 1125/50p or 1125/60p as synchronization signal. This means that our 3G-HD routers cannot use default setting.

3. Switch to handle mixed signal formats.
   The router switches 12us after vertical sync on the synchronization signal. This will occur in line 1 on all video formats. This is useful when you have different video formats on the same router, also with different frame rate.

   > This setting is not according to recommendations in SMPTE RP 168-2002. Embedded data may become damaged or lost.

3.7 Configuring protocol options

For various reasons, Nevion has decided to make it possible to turn the extra commands that were added to the NCB protocol when we introduced the Sublime router range either off or on.

At the same time, the user must select whether he/she shall use the RS-232 port for controlling the router or the Ethernet port. This is done in order to prevent both ports from simultaneously being applied for controlling the router.

There is a new Protocol field in the Nevion Configurator where you may choose from the following options;

- **NCB without Sublime ext. (RS232)**
  This is the “old” Compact NCB protocol, without Sublime extensions. If used on a Sublime, it also disables the Ethernet port of that device.
- **NCB (RS232)**
  This is the regular Sublime protocol, with the extra commands that were added to the NCB protocol. If used on a Sublime, it also disables the Ethernet port of that device. This is the default option for the *Sublime* (SL) range of products.

  > This protocol is similar to the *Triton* protocol, allowing users to connect the Sublime device to a *Jupiter VM 3000 System Controller*.

- **MRP (TCP/IP)**
  This option is only applicable to the Sublime range. It selects the Ethernet protocol as the control option, and disables the RS-232 port of that device.

  Note that the above selection is only possible if you have Sublime FW rel. 2.1.1 or newer installed on your Sublime device, and Nevion Configurator rel. 3.3.5 or newer is installed on your PC.

  It is NOT possible to select protocol options on Sublimes with HW rev. 1.

  MRP is always enabled when any TCP/IP based protocol is selected. This makes it possible to use Sublime panels when a third party protocol is selected.

- **Leitch Pass-Through (RS-232)**
  This option allows support for Leitch Pass-Through protocol via RS-232 interface. The details of this protocol are described in *Leitch Routing Switchers Serial Protocol Reference, Edition E*. See also Appendix B.1 for details.

  This option is not supported over NCB.

- **Leitch Pass-Through (TCP/IP)**
  This option allows support for Leitch Pass-Through protocol via TCP/IP interface. The details of this protocol are described in *Leitch Routing Switchers Serial Protocol Reference, Edition E.*
  The interface is using port 23 for this protocol option; same port as for Telnet applications. See also Appendix B.1 for details.

  The Leitch Pass-Through selections are only available on Sublime routers with FW version 2.4.x and higher.

- **Grass Valley Native protocol (TCP/IP)**
  This option allows support for Grass Valley Native protocol via TCP/IP interface, using port 12345. The subset of this protocol that is supported by Sublime routers and control panels is described in Appendix B.2.

  The Grass Valley Native protocol is only available on Sublime routers with FW version 2.5.4 and higher.

- **Sublime 16x2 routers with, or without extensions**
  This option shall be used only on 16x2 routers, enabling both IP, or RS-232 control and NCB extensions to other 16x2 routers in a stack.
  When using 16x2 routers in a stack, the router with the highest offset shall be connected to IP, or RS-232; and the rest of the stack interconnected with NCB connections.
  See Chapter 6.2 for connection details.

  This protocol option is *only* used on 16x2 routers; but should be used on *all* 16x2 routers in the application.

Use your Nevion Configurator to verify the HW revision of your Sublime unit:


Untitled project - System Configurator - Network Electronics ASA
File View Tools Windows Help
Close Refresh IP Settings Levels Virtual Router Mappings Categories Salvos Button Configurations
Project Explorer
Name Info
Controllers
Gyda
Control Panels
Sublime
CAA_SL_16D_CP Sublime
CAA_SL_AD3232_C.. Sublime
CAA_SL_SD1602_C.. Sublime
JGS_SL-16XY-CP Sublime
JGS_SL-8XY-CP Sublime
JGS_SL-D32P_rev2 Sublime
ref_HD3232-R-CP Sublime
SL-SD0808-N-CP Sublime
THOR_SL-8XY-CP Sublime
Sublime IP Settings
Status Hostname IP address Subnet mask Default gateway TCP connections Sublime type Firmware Bootloader HW revision MAC address
CAA_SL_16D_CP 10.10.13.100 255.255.240.0 10.10.10.254 CAA_ETHCON CP, DIP=2 1.0.4 1 00:0D:39:0A:00:64
CAA_SL_AD3232_CP 10.10.13.101 255.255.240.0 10.10.10.254 None 32x32 aes router, CP, CP, DIP=15 2.0.2 2.0.1pre1 2 00:0D:39:00:00:00
CAA_SL_SD1602_CP 10.10.13.102 255.255.240.0 10.10.10.254 None 64x16 video router, CP, DIP=10 1.0.4 1 00:0D:39:FE:01:14
JGS_SL-16XY-CP 10.10.14.8 255.255.240.0 10.10.10.254 JGS_ETHCON CP, DIP=14 1.0.5 1 00:0D:39:FF:00:1F
JGS_SL-8XY-CP 10.10.14.1 255.255.240.0 10.10.10.254 JGS_ETHCON CP, DIP=14 1.0.5 1 00:0D:39:FF:00:22
JGS_SL-D32P_rev2 10.10.14.12 255.255.240.0 10.10.10.254 None 32 ports data router, DIP=13 2.0.3 2.0.1pre1 2 00:0D:39:FF:00:2E
ref_HD3232-R-CP 10.10.11.130 255.255.240.0 10.10.10.254 None 32x32 hd router, CP, CP, DIP=4 2.0.3 2.0.3pre3 2 00:0D:39:FF:00:3A
SL-SD0808-N-CP 192.168.1.10 255.255.255.0 192.168.1.1 None 8x8 sd router, CP, DIP=2 1.0.5 1.0.5 1 00:0D:39:0A:02:D8
THOR_SL-8XY-CP 10.10.12.23 255.255.240.0 10.10.10.254 10.10.10.216 CP, DIP=0 1.0.3 1 00:0D:39:FF:00:33
aaa_gpio 10.10.13.27 255.255.240.0 10.10.10.254 aaa_ethcon CP, DIP=0 2.0.4pre1 2.0.3 2 00:0D:39:FF:00:39

Figure 2: HW verification in Nevion Configurator.

> Right-click the column headers and select the appropriate column to be shown, if you don't see the appropriate column in your default display.

For further information about FW releases, please go to the Nevion web site to download, or check available FW releases: www.nevion.com.

3.8 Configuring Input options

> This configuration is done in the Nevion Configurator.

3.8.1 Input EQ

It is possible to enable, or bypass, Input EQ for each router input separately. Default is Input EQ enabled.

3.9 Configuring Output options

This configuration is done in the Nevion Configurator.



3.9.1 Output reclocker

It is possible to enable, or bypass, Output Reclocker for each router output separately. Default is Output Reclocker enabled.

3.9.2 Slew rate settings

3.9.2.1 Slew rate mode

Set slew rate mode on output (Auto / Fixed).

Automatic slew rate detection is only available on reclocking routers. Non-reclocking routers can only set the options based on Fixed slew rate mode.

3.9.2.2 Slew rate

Set slew rate to SD or HD. Only used when Slew rate mode is fixed.

3.9.3 Laser settings

This is only applicable on Sublimes with optical I/O.

3.9.3.1 Laser enabled

Enable or disable laser; (ON / OFF). It is useful to disable a laser, for safety purposes, if maintenance is required on the receiving end of the fiber.

3.9.3.2 Laser alarm

Indicates alarm on laser; (OK / FAIL).

3.9.3.3 Laser temp alarm

Indicates high temperature alarm on laser; (OK / FAIL).

4 LED status indication

4.1 Start-up

The LED located at the front of the router indicates the status of the router. At start-up, the LED will alternate between red (R) and green (G) every 500ms for about two seconds. After the start-up sequence the LED will indicate the Alarm state of the router.

There are two LEDs located at the Ethernet bus. At start-up the boot loader is searching for update commands on the serial port for about two seconds. During this sequence both Ethernet LEDs will be blinking. After the start-up sequence the LEDs will indicate the Ethernet state.

4.2 Alarm states

The LED can either be red (R), green (G), yellow (Y) or have no light (N).

The LED state is here described with twenty letters, each representing 100ms, which totals to an alarm sequence of two seconds. The X indicates that the LED keeps the color it has the moment the alarm sequence begins (green, yellow or no light).

Description	LED state	Alarm	Comment
Continuous green light	GGGGG GGGGG GGGGG GGGGG	No alarm. Status is OK.	
Continuous yellow light	YYYYY YYYYY YYYYY YYYYY	Unable to connect to controller over Ethernet.	
Long red blinks	RRRRR NNNNN RRRRR NNNNN	Power is too low.	
One short red blink	RXXXX XXXXX XXXXX XXXXX	Power A failed	Only active if power alarm dip is set.
Two short red blinks	XXXXX XXXXX RXRXX XXXXX	Power B failed	Only active if power alarm dip is set.
Red with one short yellow blink	YRRRR RRRRR RRRRR RRRRR	No valid product key.	
Red with two short yellow blinks	YRYRR RRRRR RRRRR RRRRR	SFP error.	Only used on routers with optical modules.
Red with three short yellow blinks	YRYRY RRRRR RRRRR RRRRR	Fan error.	

4.3 Ethernet states

The LEDs that are located at the Ethernet bus will after the Start-up sequence indicate the Ethernet states:

	On	Off / Blinking
Green	Valid link	No link
Yellow	No data	Data is transmitted or received

5 Router communication

You gain access to router for communication purposes by connecting either the router's serial port to your computer or by using an Ethernet connection.

> Do not use both the router's Ethernet port and RS-232 serial port, or NCB ports, at the same time. Doing so may cause loss of important communication and control data.

5.1 Serial connection

Connection can be made through the serial port of the router; see also Chapter 2.6 for connection details.

The communication parameters are configurable. Please refer to the protocol documentation of the appropriate communication/control protocol.

Example: The protocol parameters of the *VikinX Compact routers* are as follows:

- Bit rate 19200 bit/s
- Data bits 8 bits
- Stop bits 1
- Parity: No parity

For further details concerning this protocol, please refer to the following manual:

NCB Protocol.pdf.

The DE9 female socket for the serial port of the router has the following pin-out:

Pin #	RS-232 mode
1	*Not in use*
2	Tx
3	Rx
4	*Not in use*
5	GND
6	GND
7	RTS
8	CTS
9	*Do Not Connect!*

> Note that if the standard RS-232 cable specification (DCE) is followed:
>
> A cable with Male+Male or Female+Female connectors at the cable ends is used for Rx/Tx crossed connection, and
>
> A cable with Male+Female connectors at the cable ends is used for a straight through connection.

5.1.1 Maximum cable length (RS-232)

IEEE has specified the maximum cable length for an RS-232 connection to 15m. Longer distances can be installed depending on the environmental conditions of the installation site.

> It is the responsibility of the installer / user to secure a proper installation of the RS-232 connection.

5.2 Ethernet connection

The connections follow the standard set by the IEEE 802.3 100BaseTX specification. The cables that are to be applied should be CAT-5 / CAT-5E standard, or better. It is the responsibility of the installer / user to secure a proper installation of the Ethernet connection.

All VikinX Sublime routers and IP-based Control Panels are connected together through an Ethernet Switch.

A VikinX Sublime device has only one physical Ethernet connection. If redundant control is required, this limitation has to be solved by the control system.

For Ethernet protocol details concerning this router, please refer to the following manual: Modular Router Control Protocol. This manual can be found on our web site: http://www.nevion.com.

5.2.1 HW limitations

With the introduction of Sublime controller HW Rev.2, the user has the option of connecting more than two devices together, without having a Multicon to control the network. See Chapter 3.7 for verification of the HW revision of your device.

Unless you apply a Multicon as a system controller, the limitations that apply are:

1. One Sublime control panel may connect to a maximum of 4 Sublime routers.
2. One Sublime router may be controlled by a maximum of 4 Sublime control panels.

> Exceptions to the above limitations:
>
> A router with a local CP (e.g. SL-V6464-CP) may only connect to 1 other router. Both routers must be configured with the same address and be of different type (A+V).
>
> Example: 1x SL-V6464-CP may only control itself + 1x Audio router (AA or AES). Both routers must be configured with the same address.
>
> 16x2 routers that are expanded to NNx2 (see Chapters 0 and 3.4) are using the NCB bus for this purpose. The total NNx2 router is therefore counted as 1 router in the limitations 1 and 2 above.

From limitations 1 and 2 above, the resulting Ethernet configuration may consist of maximum 8 devices; 4 routers and 4 control panels, with the exceptions mentioned above. An example is illustrated in the figure below.



Figure 3: Ethernet connections and configuration.

Refer to the Nevion Configurator User Manual for further information about the above described configuration/connection options.

It is NOT possible to connect more than 2x Sublimes with HW rev. 1 together via Ethernet, unless a Multicon is applied as system controller.

5.3 NCB connection

Via the Network Control Bus system several routers and control panels can be interconnected.

Up to 16 levels of routers, or combinations of routers, can be controlled. The NCB system and all RS 232 ports interchange the system status. This means that any control system, either from Nevion, or from a third party manufacturer, connected to any RS 232 port in the NCB loop, will have access to all communication data on the bus.

5.3.1 Connecting control panels

To get a control panel working with a specific router, configure the control panel to the same level as the router. Several panels can be configured to control the same router. Panels can also be connected to a router via the RS-232 interface. Please refer to your control panel manual for installation.

5.3.2 Pin-out and cable type

VikinX Sublime routers and Control Panels use RJ45 connectors for the Network Control Bus ports. The following pin-out is used:

Pin #1	Not Connected
Pin #2	Not Connected
Pin #3	Data (retour)
Pin #4	Data
Pin #5	Data
Pin #6	Data (retour)
Pin #7	Not Connected
Pin #8	Not Connected



The following connection example shows connection of 4 VikinX devices with RJ45 connectors and bus termination:



Figure 4: NCB loop configuration.

Note that each device at the end of the chain has a termination plug, indicated with the letter “T”. This termination plug must be inserted in the correct connection port. If not, no NCB communication is possible.

5.3.3 Termination plug

The termination plug that is mentioned in the previous chapter is necessary when you want to avoid closing the loop be a (long) cable.

The termination plug is a standard RJ45 plug with the following internal wiring:



Figure 5: NCB loop termination plug.

As seen in the figure above, *Pin 3* is connected to *Pin 4*, and *Pin 5* is connected to *Pin 6*.

5.3.4 Control bus structure

The Network Control Bus structure follows the standard MIDI bus definition. The NCB is defined as a closed chain of units. This means that the NCB OUT of the last unit must be connected to the NCB IN of the first unit in the NCB chain. To avoid problems with the control of VikinX units the installer/user has to assure that the bus structure is installed according to this definition.

The total number of VikinX devices in an NCB chain is limited to 50.

5.3.5 Maximum distance between NCB devices

The standard MIDI definition allows a maximum cable length of 200-250 meters between two devices. Longer distances can be made with MIDI repeater units. To avoid grounding problems all NCB ports have opto-coupled inputs.

6 Connecting signal cables to the router

6.1 Video signals

The Sublime Video Router offers standard 75Ohms BNC connectors for video in- and outputs. All video inputs are terminated with 75Ohms.

I/O on partly configured routers starts from I/O #1 and up.

6.2 Input extension

This chapter is only applicable for SL-SD1602 (16x2) routers.

This chapter does *not* apply to partly configured (16x1) routers.

Please refer to Chapter 0 regarding input offset.

SL-SD1602 allows input extension up to 64x2. An extension router is used to collect the signal from several units. The labels on the rear connectors in question are shown below, for the purpose of pre-wiring.



Figure 6: Input extension connectors.

Please connect the routers as shown below.



Figure 7: SL-SD3202 wiring diagram.



Figure 8: SL-SD4802 wiring diagram.



Figure 9: SL-SD6402 wiring diagram.

7 Control Panel operation

This chapter is only applicable for routers with the optional local control panel.

All local control panels are completely configurable with the Nevion Configurator, which is downloadable from the Support pages at http://www.nevion.com/

All local control panels are given a default configuration, which includes the buttons “A/V Toggle”, “Panel Enable”, “Take on/off” and “Take”. In addition input and output buttons are preconfigured.

Remember to re-program the local control panel on 16x2 routers with input offset >0.

If input offset (ref. Chapter 3.2.2) is >0, ALL Input buttons on that router must be re-programmed in order to operate on the associated router inputs.

7.1 Button description

7.1.1 A/V Toggle

The A/V Toggle button enables/disables audio and video on a specified address. The address can either be read from the dip switches, or be fixed. The button toggles between three states.

If the button is pressed for more than 1 second, it will go into a fourth state where both audio and video are disabled.

In this state the button will be dimmed. If the button is pressed for more than 1 second again, it will enable both audio and video if present.

Button Color	Video Enabled	Audio Enabled
Yellow	Yes	Yes
Green	Yes	No
Red	No	Yes
Dimmed	No	No

Toggle status changes will be stored in flash and used when the panel is powered up later.

The following information is only valid for Sublime FW version 2.5.3 and older:

If neither audio nor video is present, it will be marked as disabled and the toggle state will not be used.

When a panel is powered on it will search for connected routers. If no routers are found the A/V Toggle button will be disabled (no light in the button).

This can happen if the panel is powered up before any routers are connected or if there is something wrong with the cabling.

To re-enable the A/V Toggle do the following:

1. Activate the *Panel Enable* button (Green light).

2. Push & Hold the A/V Toggle-button for 2 seconds.

The A/V Toggle-button should now be activated and the light turned on.

7.1.2 Panel Enable

The panel always starts in disabled mode. In this state the button will be red and all the other buttons will be disabled. When pressing the button the panel will be enabled and the color will change to green. A status request will also be sent to get information on active levels.

7.1.3 Take on/off

The Take on/off button enables or disables the Take button. If no take button is defined, Take on/off is always off. On first start-up the take button is enabled. Later it will read the last status from the flash memory.

7.1.4 Take

The Take buttons LED is normally off. If the Take on/off button is set to “on”, no commands will be sent from the panel until the Take button is pressed. The last selected buttons and the take button will blink, until the Take button is pressed and the command is sent from the panel.

7.1.5 Output

An Output button is used for selecting an output. Selecting an output activates it, so that it is switched to the next input that is selected.

7.1.6 Input

An Input button switches the active output to the selected input. If the Take button is enabled, the switch will not be executed until the Take button is pressed.

When switching using the Input button, all enabled audio- and video-levels will be switched from the selected input to the active output.

> The Input button can also be used to select the active output. This is useful on single bus panels. It requires that a *Panel Enable* button is present. When the panel is enabled, press the *Panel Enable* button and hold it while selecting the active output by pressing an *Input* button. Then release the *Panel Enable* button. The panel will now be disabled. Press the *Panel Enable* button again to enable it.

7.1.7 XY

An Input to Output (XY) button switches a preset input to a preset output on all enabled audio- and video-levels. If the Take button is enabled, the switch will not be executed until the Take button is pressed.

> The maximum router size(s) that may be controlled without Multicon is formed by IN#1-128 and OUT#1-64 (router size: 128x64). This size limitation is regardless of the number of routers the control panel(s) is/are controlling.
>
> See also the limitations 1 and 2 in Chapter 5.2.1.

7.1.8 Salvo

A Salvo button switches a sequence of X-points. This is done even if the specified audio- or video-level is disabled.

Salvo limitations on Sublime routers with local control panels:

> 1 level (audio + video) up to 128x128;
>
> 20 salvos of max 64 X-points each.

Salvo limitations on Sublime stand-alone control panels:

> 4 levels (audio + video) up to 128x128;

20 salvos of max 64 X-points each.

7.1.9 Lock

A Lock Toggle button toggles the lock-status on the active output on all enabled audio- and video-levels. If the active output on any of the enabled levels is locked before pressing the button, they will be unlocked. If not the active output on all enabled levels will be locked. A locked output can’t be switched.

7.1.10 Protect

A Protect Toggle button toggles the protect-status on the active output on all enabled audio- and video-levels. If the active output on any of the enabled levels is protected before pressing the button, it will become unprotected. If not, the active output on all enabled levels will be protected. A protected output can’t be switched by anyone else but the user that protected it.

General environmental requirements for Nevion equipment

1. The equipment will meet the guaranteed performance specification under the following environmental conditions:
   - Operating room temperature range: 0°C to 45°C
   - Operating relative humidity range: <95% (non-condensing)

2. The equipment will operate without damage under the following environmental conditions:
   - Temperature range: -10°C to 55°C
   - Relative humidity range: <95% (non-condensing)

Product Warranty

The warranty terms and conditions for the product(s) covered by this manual follow the General Sales Conditions by Nevion, which are available on the company web site:

www.nevion.com

Important notes regarding Software in the VikinX Sublime router family range

This product utilizes software components that are licensed with open source licenses. The source code for these components and our modifications are available from: http://labs.nevion.com/open-source/

OpenTCP includes software developed by Viola systems (http://www.violasystems.com/).

Appendix A Materials declaration and recycling information

A.1 Materials declaration

For product sold into China after 1st March 2007, we comply with the “Administrative Measure on the Control of Pollution by Electronic Information Products”. In the first stage of this legislation, content of six hazardous materials has to be declared. The table below shows the required information.

組成名稱 Part Name	Toxic or hazardous substances and elements					
	鉛 Lead (Pb)	汞 Mercury (Hg)	镉 Cadmium (Cd)	六价铬 Hexavalent Chromium (Cr(VI))	多溴联苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
All products referred to in Chapter 1.1	O	O	O	O	O	O
SL-PWR-40 / SL-PWR-90	O	O	O	O	O	O
O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363-2006. X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363-2006.						

Parts without any of the above mentioned hazardous substances are indicated by the product marking:

A.2 Recycling information

Nevion provides assistance to customers and recyclers through our web site http://www.nevion.com/. Please contact Nevion’s Customer Support for assistance with recycling if this site does not show the information you require.

Where it is not possible to return the product to Nevion or its agents for recycling, the following general information may be of assistance:

- Before attempting disassembly, ensure the product is completely disconnected from power and signal connections.
- All major parts are marked or labeled to show their material content.
- Depending on the date of manufacture, this product may contain lead in solder.
- Some circuit boards may contain battery-backed memory devices.

Appendix B Additional Protocol information

B.1 Leitch Pass-Through protocol

This protocol is available in Sublime firmware 2.4.0 and later.

The Sublime implementation of Leitch Pass-Through supports all commands described in "Leitch Routing Switchers Serial Protocol Reference, Edition E".

In the command "Alarms Status Request", a bit-field is used for reporting active alarms. In Sublime, the bit-field is used as in the table below.

Bit	Description	Reported from firmware version
0	Power A failed	2.4.0
1	Power B failed	2.4.0
2	Positive power too low	2.4.0
3	Negative power too high	2.4.0
4	Client TCP/IP connection failed	2.4.0
5	No valid product key	2.4.0
6	SFP error	2.4.0
7	EXT IN not locked	2.5.4
8	EXT IN CRC error counting	2.5.4
9	Fan error	2.6.2

B.2 Grass Valley Native protocol

This protocol is available in Sublime firmware 2.5.4 and later.

Sublime does not support all commands available in this protocol. The supported commands are described in the table below.

<table>
<tr><th>Command</th><th>Parameter</th><th colspan="3">Comments</th></tr>
<tr><td rowspan="2">BK - Background Activities</td><td>E - Echo</td><td colspan="3">BK,E and BK,E,ON and BK,E,OFF are all accepted and will be responded with ER,00,BK.</td></tr>
<tr><td>R - Protocol Processor Software Revision #</td><td colspan="3">Will be responded with KB,R,<firmware version>,</td></tr>
<tr><td>TJ - Request Take Index With Level Bitmap</td><td></td><td colspan="3">Each command supports only one X-point.</td></tr>
<tr><td>TI - Request Take Index With Level Index</td><td></td><td colspan="3">The optional level Index is not supported. The command can only be used to switch all levels.</td></tr>
<tr><td rowspan="5">QH - Query alarm status</td><td rowspan="5">AC - Query active alarm status</td><td colspan="3">Sublime has defined the alarms defined in the table below. All active alarms will be responded on this request.</td></tr>
<tr><td>Alarm ID</td><td>Alarm Name</td><td>Alarm Parameter</td></tr>
<tr><td>0x0101</td><td>Frame Fan</td><td>Fan number</td></tr>
<tr><td>0x0105</td><td>Power-supply</td><td>01 - Power A failed
02 - Power B failed</td></tr>
<tr><td>0x010A</td><td>Positive power too low</td><td>Always 00</td></tr>
</table>

		0x010B	Negative power to high	Always 00
		0x010C	Client TCP/IP connection failed	Always 00
		0x010D	No valid product key	Always 00
		0x010E	SFP error	Always 00
		0x010F	EXT IN not locked	Always 00
		0x0110	EXT IN CRC error counting	Always 00
QN - Query Names	L - Level			
	IS - Sources with source indexes	On SL-D32P+ the next available source will be labeled "DISCONNECT" and used to disconnect destinations.		
	ID - Destinations with destination indexes			

EC Declaration of Conformity

MANUFACTURER	Nevion Europe AS P.O. Box 1020, 3204 Sandefjord, Norway	
AUTHORIZED REPRESENTATIVE (Established within the EEA)	Not applicable	
MODEL NUMBER(S)	All VikinX Sublime 1RU, 2RU and 4RU routers.	
DESCRIPTION	3G/HD/SD-SDI Video Routers in the VikinX Sublime series	
DIRECTIVES this equipment complies with	Low voltage (EU Directive 2006/95/EC) EMC (EU Directive 2004/108/EC) RoHS (EU Directive 2002/95/EC) China RoHS[1] WEEE (EU Directive 2002/96/EC) REACH	
HARMONISED STANDARDS applied in order to verify compliance with Directive(s)	EN 55103-1:1996 EN 55103-2:1996 EN 55103-1:2010 EN 55103-2:2010	
TEST REPORTS ISSUED BY	**Notified/Competent Body**	**Report no:**
	Nemko Nemko Central Research Laboratory	E08443.00 E08443.01 09500570
TECHNICAL CONSTRUCTION FILE NO	Not applicable	
YEAR WHICH THE CE-MARK WAS AFFIXED	2008 2011 2010	
TEST AUTHORIZED SIGNATORY		
MANUFACTURER	**AUTHORIZED REPRESENTATIVE (Established within EEA)**	**Date of Issue**
		2011-01-28
		Place of Issue
	Not applicable	Sandefjord, Norway

NEVION EUROPE AS
O.nr. 976 584 201 MVA

Name Thomas Øhrbom

Position VP of Business Support Systems, Nevion
(authorized signature)

[1] Administration on the Control of Pollution Caused by Electronic Information Products